



INSTALLATION INSTRUCTIONS

LAMINATE

GENERAL

- a. Before proceeding to the flooring installation, always make sure that the climatic conditions of the room are suitable:
 - Temperature: 15°C -20°C
 - Relative Humidity: 45%-60%
- b. It is recommended to store the floor (in the boxes) in the room that will be installed, for at least 24 hours before installation for acclimatization.
- c. In cases of installation over underfloor heating, follow the instructions of the manual «Underfloor Heating – Technical Instructions for Underfloor Heating»
- d. In cases of defective substrate (cement screed, tiles, old wooden floor), follow the instructions of the manual «Solutions for Problematic Substrates»

INSTALLATION INSTRUCTIONS FOR LAMINATE

LAMINATE floorings can be installed **floating** on any even and flat surface:

1: Measure the flatness of the cement screed. The height differences must not exceed 3mm, at a distance of 1 meter. The cement screed must be thoroughly cleaned.

2: Measure the moisture level of the cement screed by using a hygrometer (eg. MAPEI). The indication must not exceed 3%.

3: Choose one of the following **RELMAT** underlays:

- *CELLMAT* for installations with no specific requirements
- *R-FLEX* for increased moisture
- *ACOUSTICORK* for thermal / sound insulation

4: Apply the selected underlay

6: For the installation of **RELMAT LAMINATE** follow the instructions of the inlay sheet that you can find in every RELMAT laminate box. The photos will clearly help you install your floor fast and easily.



New concept



NOTES

- **RELMAT LAMINATE** boards must not lean on any vertical surface of the room. Always maintain a distance of 10mm – 12mm
- It is not necessary to use adhesive, but in case it is required, use Class D3
- ATTENTION: **RELMAT LAMINATE** can not be installed over electric subfloor heating